

Sandero III (BJI),1.0 SCE PETROL ENGINE,JH3,TEKNA UU1DJF00667450249 | FZ935LH

MAINTENANCE PROGRAM

OPERATIONS TO BE CARRIED OUT AT THE MILEAGE OR TIME INTERVAL, WHICHEVER IS REACHED FIRST:	Fr	om	Every	
The maintenance programme, the intervals and the standards for products and consumables, must be observed during the warranty period and apply in the country where your vehicle was sold. Outside the country of origin, please consult a representative for the brand.	КМ	YEAR(S)	КМ	YEAR(S)
Dacia B service(1)(*)			30000	2.0
Dacia A service(2)(*)		1.0	30000	2.0
Drain the engine oil			30000	2.0
Replace the oil filter			30000	2.0
Replace the air filter			60000	4.0
Replace the spark plugs			60000	4.0
Replace the brake fluid			120000	3.0
Replace the coolant			150000	5.0
Replace the accessories belt and rollers			150000	6.0
Replace the cabin filter		1.0	30000	2.0

^{(*)*\/}See the content of these services below

THE FOLLOWING OPERATIONS MUST BE CARRIED OUT DURING THE SERVICE:

	(1)	(2)
Check the condition and pressure of the tyres and road wheel security	>	>
Check the levels, condition and sealing of the cooling circuit	>	
Check the levels, condition and sealing of the sequential gearbox circuits (if fitted)	~	
Anti-corrosion check		~
Check the condition and sealing of the front shock absorbers	~	
Check the condition and sealing of the rear shock absorbers		~
Check the engine oil level		~
Check the condition and sealing of the gaiters/rubber mounting bushes/ball joints		~
Reinitialise the maintenance/oil service display	>	>
Documentation and positioning of the maintenance label	>	>
Check the wiper blades and screen washer fluid levels	~	
(1) Dacia R service	-	

	(1)	(2)
Check the condition of the windscreen and door mirrors	>	~
Check the operation of the instrument panel warning lights	~	>
Check the exhaust pipe		>
Check the levels, condition and sealing of the hydraulic power- assisted steering circuit (if fitted)	~	
Check the levels, condition and sealing of the clutch/front brake circuit	~	
Check the levels, condition and seals of the rear brakes		~
Check the presence of the wheel valve caps	>	~
Check the presence of the airbag and engine compartment labels	>	
Check the signalling and exterior/interior lighting	>	~
Check the wear of the front brake discs and pads	~	
Check the wear on the rear brake pads and discs (if fitted)		~



⁽¹⁾ Dacia B service (2) Dacia A service

Important: The manufacturer recommends adapting the replacement frequency for certain parts or fluids that are affected by particular conditions of use. Please refer to the attached sheet for further details

Your vehicle is fitted with a device for monitoring the oil quality that will warn you if an early service is required in the event of particular conditions of use. Please refer to the attached sheet for further details

Service A and cabin filter: if you travel more than 9,000 miles (15,000 km) per year, these two operations are to be carried out every 18,000 miles (30,000 km) or 1 year, whichever is reached first.



FLUIDS: Please observe the manufacturer's recommendations carefully

ENGINE OIL

NORME: RN 17 Average capacity: 3.40 Litres

Grades to use according to the external temperature:

ordaes to use according to				
	0 °C	RN 17		
Above:	-15 °C	5W30		
	-20 °C	5W30		
	-25 °C	5W30		
	-30 °C	0W40		

The manufacturer recommends:



BRAKE FLUID

Type DOT 4+, ISO CLASS 6, NORME RENAULT: 03-50-006

COOLANT

Type GLACEOL RX type D

The use of engine oil additive during the warranty period is prohibited by the manufacturer and not recommended after this period.

